



the original since 1921

Overhead Door Company of Louisville

www.odclou.com

502-530-4019

**CODING INSTRUCTIONS
FOR 1998 and LATER CARS**

**Homelink
Built-in
Transmitter**

**NOTE: CARS MADE AFTER
JANUARY 1, 1997 CAN
ONLY BE USED WITH
ROLLING CODE OR
390 FREQUENCY
TRANSMITTERS.**

**CARS MADE BEFORE
JANUARY 1, 1997 WILL
WORK ON ALL
NON ROLLING CODE
TRANSMITTERS.**

Press and hold the two outside buttons on the headliner until the small icon light does something different (sometimes this takes 20 to 30 seconds). Release the buttons.

Hold the existing transmitter within 2 inches of the headliner and press and hold the transmitter button, while you are doing this press and hold the appropriate button on the headliner. Hold both of these buttons until the small icon light does something different.

Press and release the Learn Code button on the back of your door opener, it can be found within about an inch of where the antennae wire disappears into the motor head.

Go back to the car and press the appropriate button on the headliner slowly 4 times.

